


## Big Tic: Dial Changes Color

*Dial changes color at the push of a button.*



### Demo Mode

*This watch ships in the demo mode, showing the display colors alternating for two seconds each.*

1. To take out of demo mode, press and hold the pusher for two seconds.
2. To put back into demo mode, press and hold the pusher for two seconds.

### Changing Colors

1. Make sure that it is out of demo mode.
2. Press the pusher to show color 1.
3. Press the pusher again to show color 2.

*If you prefer to have the colors alternating, simply put the watch back into demo mode.*

### Time Setting

1. Pull crown out to position 2.
2. Turn crown to set the desired time.
3. Return crown to position 1.