


Fuel Ana-Digi Module



Normal Time Display

1. Press A to toggle 12/24H format.
2. Press B to change display mode. Display mode sequence is time, calendar, seconds.

Time/Calendar Setting

1. From any display mode, press and hold A to enter setting mode; year will begin flashing.
 2. Press B to advance setting value. Press and hold B for fast advance.
 3. Press A to set and advance to next setting value.
 4. Setting sequence is: year, month, date, hour, minute.
 5. Setting will automatically return to display mode after minute is set, or if no pusher is operated for 30 seconds.
- NOTE: When setting hour, digits are in 24 hour display.*