


Square Time Grid



ONE	00		
TWO	05		
THREE	10		
FOUR	15		
FIVE	20		
SIX	25		
SEVEN	30		
	35		
NINE	40		
TEN	45		
ELEVEN	50		
TWELVE	55		

Press A to change digital display mode.

Time Setting

1. From any display mode, press and hold A for 2 sec to enter setting mode; hour will begin flashing.
2. Press A to advance setting value.
3. Press and hold A for 2 sec to advance to minute setting, minute will begin flashing.
4. Press A to advance setting value.
5. Press A and hold for 2 seconds to exit setting mode and return to display mode.
6. Setting will automatically return to display mode if no pushers is operated for 20 seconds.