


Day/Date Watch VX43

(1 crown)



Date Setting

1. Pull the crown out to position 2.
2. Turn counter-clockwise and set the date for the previous day.

Day Setting

With crown still in position 2, turn clockwise and set the day for the previous day.

Time Setting

1. Pull crown out to setting 3.
2. Turn counter-clockwise to advance the time, and continue until the day/date changes to the present day.
3. Set the correct time.
4. Push crown back to position 1.

Day/Date Watch VX36

Date and Time Setting

1. Pull the crown out to position 3.
2. Turn the crown clockwise to advance hour and minute hands.
The hand showing day of the week will also move with the hour and minute hands. Keep turning the crown until you have reached the desired day.

Date Setting

1. Pull crown out to position 2.
2. Turn the crown clockwise to advance date hand.