


Big Tic World Time Module



Normal Time Display

1. Press pusher A to change mode.
2. Press pusher B for EL.

NOTE: In any setting mode if no pusher is operated for 20 seconds, display will return to normal display.

Time Setting

1. From normal time display, press and hold pusher D for 2 seconds to enter time setting mode; seconds will begin flashing.
2. Press pusher C to reset seconds to zero.
3. Press pusher A to select hour, minutes, 12/24 hour format, and time zone.
4. Press pusher C to advance values; press and hold pusher C for fast advance.
5. Press pusher D to exit time setting mode.

Alarm Mode

1. Press pusher A to select alarm setting mode.
2. Press pusher C to turn alarm/chime on/off.
3. Press and hold pusher D for 2 seconds to enter alarm setting mode; hour will begin flashing.
4. Press pusher A to select hour and minutes.
5. Press pusher C to advance value; press and hold pusher C for fast advance.
6. Press pusher D to exit alarm setting mode.

Chronograph Mode

1. Press pusher A to select chronograph mode.
2. Press pusher C to start/stop chronograph.
3. While chronograph is running, press pusher D for split time.
NOTE: The record will be on the display for 5 seconds and then move to the next split and continue counting.
4. Press pusher D to reset to zero.

World Time Mode

1. Press pusher A to select world time mode.
2. Press pusher C to increase the time zone; press pusher D to decrease the time zone.
3. Press pusher A to confirm the time zone; "DST" will be displayed.
4. Press pusher C to toggle yes/no.

24 Time Zones Description

Time Zone	City Code	City Name	Time
1	SAM	Samoa	1:00
2	HNL	Honolulu	2:00
3	ANC	Anchorage	3:00
4	LAX	Los Angeles	4:00
5	DEN	Denver	5:00
6	CHI	Chicago	6:00
7	NYC	New York	7:00
8	CCS	Caracas	8:00
9	RIO	Rio De Janeiro	9:00
10	REC	Recife	10:00
11	AZO	Azores	11:00
12	LON	London	12:00
13	PAR	Paris	12:00
14	CAI	Cairo	14:00
15	MCW	Moscow	15:00
16	DXB	Dubai	16:00
17	KHI	Karachi	17:00
18	DAC	Dacca	18:00
19	BKK	Bangkok	19:00
20	HKG	Hong Kong	20:00
21	TYO	Tokyo	21:00
22	SYD	Sydney	22:00
23	NOU	Noumea	23:00
24	WLG	Wellington	0:00