


Alarm Chronograph Stopwatch YM62A



Time Setting

1. Pull crown out to position 3.
2. Turn crown to set the desired time.
3. Return crown to position 1.

Date Setting

1. Pull crown out to position 2
2. Turn crown clockwise until the correct date is shown in the date window.
3. Return crown to position 1.

Using the Stopwatch

1. Press A to start/stop the stopwatch.
2. Press B to control the split time and reset.

Using the Alarm

1. Pull crown out to position 2.
2. Press B to set alarm time, continuously pressing for quick setting.
3. Return crown to position 1.
4. Press A to stop alarm chime.
5. Alarm hands return to current time after alarm chimes.

NOTE: If alarm does not chime, alarm needs to be reset. See below for reset instructions.

Chronograph Zero Reset and Alarm Reset

1. Pull crown out to position 3. Chronograph second hand and minute hand will return to "0." Alarm hands will move to current time. If hands do not move to current time, alarm needs to be reset.
2. Press B (continuously pressing for quick set) to reset alarm hands to current time.
3. Press A for 2 seconds to reset chronograph minute hand.
4. Press B to set chronograph minute hand to "0" position.
5. Press A for 2 seconds to reset chronograph second hand.
6. Press B to set chronograph second hand to "0" position.
7. Return crown to position 1.