


Chronograph JS50



Time Setting

1. Pull crown out to position 2.
2. Turn crown clockwise to set time.
NOTE: 24-hour hand moves correspondingly with the hour and minute hands. When setting the time be sure to check that the 24-hour hand is set properly.
3. Return crown to position 1.

Chronograph Operation

1. Press A to start/stop the chronograph.
2. Press B to reset.
NOTE: Chronograph will automatically stop after running continuously for 30 minutes.

Chronograph Zero Reset

1. Pull crown out to position 2.
2. Press A to move second hand to the 12:00 (zero) position. Each press advances the chronograph second hand one mark. Press and hold A for fast advance.
NOTE: Chronograph minute hand is synchronized with chronograph second hand.
3. Once the hands have been zeroed, reset the time and return crown to position 1.