


Chronograph with Date OS62



Time/Day Setting

1. Pull crown out to position 3.
2. Rotate crown to set time.
3. Return crown to position 1.

Date Setting

1. Pull crown out to position 2.
2. Rotate crown counter-clockwise until the correct date is shown in the date window.
3. Return crown to position 1.

Chronograph Operation

1. Press B to enter chronograph mode.
2. Press A to start/stop the chronograph.
3. Press B to reset.

NOTE: Actual measurement in the 1/20 second eye will be displayed when A is pressed to stop the chronograph.

Chronograph Zero Reset

This procedure should be performed when the chronograph second and 1/20 second hands do not return to the zero position after the chronograph has been reset.

1. Pull crown out to position 3.
2. Press A to set chronograph second hand to the zero position. Press and hold A to move the hand quickly.
3. Press B to set chronograph 1/20 second hand to the zero position. Press and hold B to move the hand quickly.
4. Once the hands are "zeroed," reset time and return crown to position 1.
5. Press B to check that chronograph hands are reset to zero position.

NOTE: Do not return crown to position 1 while chronograph second hand or chronograph 1/20 second hand is returning to zero. Doing so will cause the position of the hands to be recognized as the new zero position.