


Multifunction Ana-Digi



Normal Time Display

1. Press A to change mode.
2. Press B for EL.
3. Press C to toggle 12/24 hour format.

Time/Calendar Setting

1. From normal time display, press A three times to enter setting mode, seconds will begin flashing.
2. Press C to reset seconds to zero.
3. Press D, hour will begin flashing.
4. Press C to advance digit. Press and hold C for fast advance.
5. Press D to set and advance to next setting value.
6. Setting sequence: seconds, hour, minutes, date, day.
7. Press A to exit setting mode and return to normal time display.
NOTE: Setting will automatically return to normal time display if no pusher is operated for 2 minutes.

Alarm Mode

1. From normal time display, press A once to select alarm mode.
2. Press C to toggle alarm/chime on/off.
3. Press and hold C for alarm sound testing (alarm will continuously beep).
4. Press D to enter alarm setting mode.
5. Press D to select hour and minute.
6. Press C to advance digit; press and hold C for fast advance.
7. Press A to exit setting mode and return to normal time display.

Chronograph Mode

1. From normal time display, press A twice to select chronograph mode.
2. Press C to start/stop the chronograph.
3. Press D to reset to zero when the chronograph is stopped.

Split Time

1. Press D while the chronograph is running.
2. Press D again to return to the chronograph.
3. Press C to repeat start/stop for split time.
4. Press D to finalize timing.
5. Press D to reset to zero.