


## Ana-Digi ZAD52-F



### Normal Time Display

1. Press A to change mode. Mode sequence is time, date, chronograph.
2. Press C to toggle 12/24-hour format.

*NOTE: In any setting mode, if no pusher is operated for 1 minute, all changes will be saved and the setting will automatically return to normal time display mode.*

### Time And Calendar Setting

1. In normal time display, press and hold B for 3 seconds; hour will begin flashing.
2. Press C to increase hour; press D to decrease hour. Press and hold C for fast advance increment or D for fast advance decrement.
3. Press B to advance to minutes.
4. Press C to increase digit; press D to decrease digit. Press and hold C for fast advance increment or D for fast advance decrement.
5. Press B to set and advance to next setting value.
6. Setting sequence is: hour, minute, year, month, date.
7. Press B to exit setting mode.

### Chronograph Mode

1. Press A to change to chronograph mode.
2. Press C to start the chronograph; press D to stop the chronograph.
3. Press D to reset to zero.