


## Ana-Digi QG2014-AB



### Normal Time Display

1. Press A to change mode. Mode sequence is: normal time, chronograph, alarm setting, time setting.
2. Press B for EL.
3. Press C to display date.
4. Press D to display alarm.
5. Press C+D to toggle alarm on/off.
6. Press A+D to toggle chime on/off. All weekdays will be displayed for chime on.

### Chronograph

1. Press A to change to chronograph mode.
2. Press C to start/stop the chronograph.
3. Press D to reset to zero.

*NOTE: While the chronograph is running, press A to return to Normal Time Display. Chronograph will continue running in the background.*

### Split Time Measurement

1. Press D while the chronograph is running.
2. Press C to return to chronograph.
3. Press C to finalize timing.
4. Press D to scroll through all laps.
5. Press D to reset to zero.

### Alarm Setting

1. Press A to change to alarm setting mode; hour will begin flashing.
2. Press C to increase digit; press and hold C for fast advance.
3. Press D to set and advance to minutes.
4. Press C to increase digit; press and hold C for fast advance.
5. Press A to exit setting mode and return to Normal Time Display.

*NOTE: Alarm will sound for one minute. Press D to stop alarm sound; press C for 5 minute snooze.*

### Time/Date Setting

1. Press A to change to time setting mode; seconds will begin flashing.
2. Press C to reset seconds to zero.
3. Press D to advance to minutes.
4. Press C to increase digit; press and hold C for fast advance.
5. Press D to set and advance to next setting value.
6. Setting sequence is: seconds, minutes, hour, day, month, weekday.
7. Press A to return to Normal Display.

*NOTE: When setting the hour, "H" is displayed for 24 hour format; "A" or "P" for 12 hour format.*